

R-Series Filter Requirements - Pleated Filters								
Model	Filter Location	Filter Size	Filter Qty Req'd	Fill Piece Qty	Fill Piece Size (width)			
					No Insulation	1" Insulation	1" Double Wall	2" Double Wall
R327	SAFS, FMB, FIH	16x20 20x20	8 4	4	5 1/4	3 1/4	2 5/8	1 5/8
R330 & R336	SAFS, FMB	16x20 20x20	9 18	6	7 1/4	5 1/4	4 5/8	3 5/8
	FIH	16x20 20x20	9 15	5	7 1/4	5 1/4	4 5/8	3 5/8
R340	SAFS, FMB, FIH	12x20 16x20 20x20	12 18 9	6	4 1/4	2 1/4	1 5/8	5/8
R344 & R349	SAFS, FMB	16x20 20x20	35 9	7	6 1/4	4 1/4	3 5/8	2 5/8
	FIH	16x20 20x20	30 9	6	6 1/4	4 1/4	3 5/8	2 5/8
R354	SAFS, FMB, FIH	16x20 20x20	24 16	8	6 1/4	4 1/4	3 5/8	2 5/8
R360	SAFS, FMB	16x20 20x20	9 36	9	4 1/4	2 1/4	1 5/8	5/8
		FIH	16x20 20x20	8 32	8	4 1/4	2 1/4	1 5/8
	R366	SAFS, FMB, FIH	16x20 20x20	40 20	10	5 3/4	3 3/4	2 3/4
R373	SAFS, FMB, FIH	16x20 20x20	10 50	10	4 3/4	2 3/4	1 3/4	1 3/4
R380	SAFS, FMB, FIH	16x20 20x20	80 9	10	3 3/4	1 3/4	3/4	3/4
R389	SAFS, FMB, FIH	16x20 20x20	24 60	12	6 1/4	4 1/4	3 1/4	3 1/4

R-Series Filter Requirements - Aluminum Filters								
Model	Filter Location	Filter Size	Filter Qty	Fill Piece Qty	Fill Piece Size (width)			
					No Insulation	1" Insulation	1" Double Wall	2" Double Wall
R327	SAFS, FMB, FIH	16x20 20x20	8 4	4	4 7/8	2 7/8	2 1/4	1 1/4
R330 & R336	SAFS, FMB	16x20 20x20	9 18	6	6 7/8	4 7/8	4 1/4	3 1/4
	FIH	16x20 20x20	9 15	5	6 7/8	4 7/8	4 1/4	3 1/4
R340	SAFS, FMB, FIH	12x20 16x20 20x20	12 18 9	6	3 5/8	1 5/8	1	0
R344 & R349	SAFS, FMB	16x20 20x20	35 9	7	5 5/8	3 5/8	3	2
	FIH	16x20 20x20	30 9	6	5 5/8	3 5/8	3	2
R354	SAFS, FMB, FIH	16x20 20x20	24 16	8	5 5/8	3 5/8	3	2
R360	SAFS, FMB	16x20 20x20	9 36	9	3 5/8	1 5/8	1	0
		FIH	16x20 20x20	8 32	8	3 5/8	1 5/8	1
	R366	SAFS, FMB, FIH	16x20 20x20	40 20	10	5	3	2
R373	SAFS, FMB, FIH	16x20 20x20	10 50	10	4	2	1	1
R380	SAFS, FMB, FIH	16x20 20x20	80 9	10	2 3/4	3/4	- 1/4	- 1/4
R389	SAFS, FMB, FIH	16x20 20x20	24 60	12	5 3/8	3 3/8	2 3/8	2 3/8

Note: filter quantity and sizes subject to change without notice
2/26/2025

AA-Series Filter Requirements - Pleated Filters								
Model		Filter Size	Filter Qty Req'd	Fill Piece Qty	Fill Piece Size (width)			
					No Insulation	1" Insulation	1" Double Wall	2" Double Wall
AA1700	FIH	20x25	1	n/a				
	FS	16 x25	1	1	3 1/4	1 1/4	7/8	- 1/8
AA3000	FIH	16x25	2	n/a				
	FS & FMB	12x20 16x20	2 2	2	4 3/4	2 3/4	2 3/8	1 3/8
AA1 AA2	FIH	20x20	4	n/a				
	FS & FMB	16x20 20x20	3 3	3	4 3/4	2 3/4	2 3/8	1 3/8
AA3	FIH	16x20	6	n/a				
	FS & FMB	16x20 12x20	6 3	3	5 1/4	3 1/4	2 7/8	1 7/8
AA4	FIH & FS	16x20 20x20	8 4	4	4 1/4	2 1/4	1 7/8	7/8
	FMB	16x20 20x20	10 5	5	4 1/4	2 1/4	1 7/8	7/8
AA5 AA6	FS, FIH & FMB	16x20 20x20	10 10	5	3 3/4	1 3/4	1 3/8	3/8
AA7	FS & FMB	16x20 20x20	21 14	7	4 1/4	2 1/4	1 7/8	7/8
	FIH	16x20 20x20	18 12	6	4 1/4	2 1/4	1 7/8	7/8
AA8	FS, FIH & FMB	16x20	48	8	4 3/4	2 3/4	2 3/8	1 3/8

AA-Series Filter Requirements - Aluminum								
Model		Filter Size	Filter Qty Req'd	Fill Piece Qty	Fill Piece Size (width)			
					No Insulation	1" Insulation	1" Double Wall	2" Double Wall
AA1700	FIH	20x25	1	n/a				
	FS	16 x25	1	1	3 1/8	1 1/8	3/4	- 1/4
AA3000	FIH	16x25	2	n/a				
	FS & FMB	12x20 16x20	2 2	2	4 1/2	2 1/2	2 1/8	1 1/8
AA1 AA2	FIH	20x20	4	n/a				
	FS & FMB	16x20 20x20	3 3	3	4 1/2	2 1/2	2 1/8	1 1/8
AA3	FIH	16x20	6	n/a				
	FS & FMB	16x20 12x20	6 3	3	4 7/8	2 7/8	2 1/2	1 1/2
AA4	FIH & FS	16x20 20x20	8 4	4	3 7/8	1 7/8	1 1/2	1/2
	FMB	16x20 20x20	10 5	5	3 7/8	1 7/8	1 1/2	1/2
AA5 AA6	FS, FIH & FMB	16x20 20x20	10 10	5	3 1/4	1 1/4	7/8	- 1/8
AA7	FS & FMB	16x20 20x20	21 14	7	3 5/8	1 5/8	1 1/4	1/4
	FIH	16x20 20x20	18 12	6	3 5/8	1 5/8	1 1/4	1/4
AA8	FS, FIH & FMB	16x20	48	8	4	2	1 5/8	5/8

Note: filter quantity and sizes subject to change without notice
2/26/2025